

4. REMOTE CONTROL UNIT [AXD7273]

4.1 CONTRAST OF MISCELLANEOUS PARTS


- NOTES :
- Parts marked by “ NSP ” are generally unavailable because they are not in our Master Spare Parts List.
 - The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screw adjacent to ▼ mark on the product are used for disassembly.
 - Reference Nos. indicate the pages and Nos. in the service manual for the base model.

■ CONTRAST TABLE

AXD7273 and AXD7266 are constructed the same except for the following:

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			AXD7266	AXD7273	
P100-3		Rubber Sheet	AZA7397	AZA7402	
P100-15		Case A Assy	AZA7864	AZA7863	

■ REMOTE PCB MODEL SWITCH



MODEL SWITCH

Model	JP10	JP11	JP20	JP21	JP30	JP31
AXD7257, AXD7278	—	○	—	○	—	○
AXD7258, AXD7279	—	○	—	○	○	—
AXD7259	—	○	○	—	—	○
AXD7266	—	○	○	—	○	—
AXD7273	○	—	—	○	—	○
AXD7275	○	—	—	○	○	—